




READ ME FIRST!!!

Please remove the protective cover from potentiometer before installing on system.
If not removed, damage to the system may occur.



This cover is used to protect the potentiometers during shipping.

Please place protective cover on core returns.

This part has tamper-proofing in place. If part has been tampered with, without prior authorization, the part will be treated as an exchange and credit will not be issued.